

Congratulations on your Guide Gear® purchase.

Enjoy your new Guide Gear® item with confidence, knowing it has been designed and built to deliver dependable quality and performance at an exceptional value.

Item #623496 Guide Gear® XL Magnum Cot



For assistance with your product, please contact Sportsman's Guide customer service at 1-800-888-3006 Mon.-Fri. 7:00am to 9:00pm, Sat.-Sun. 8:00am to 8:00pm CST or go to sportsmansguide.com/customerservice/contactus



Parts List

- 1 Carry Bag
- 1 Cot Base
- 2 End Bar Supports

No Tools Required for Assembly



WARNINGS & CAUTIONS

- Read and understand all warnings, cautions, assembly and use instructions prior to assembling, installing or using this product. Failure to follow all warnings, cautions and instructions may result in serious injury or damage to personal property.
- Confirm all parts are present before assembly. If any part is missing, cracked or damaged, please contact Sportsman's Guide customer service before assembly.
- NEVER exceed the weight limit of 600 pounds (272 kg).
- Once assembled, ALWAYS make sure the product is placed on a firm, level surface.
- NEVER stand on the cot.
- ALWAYS make sure the cot is completely dry before storing in the carry bag.
- The warnings, cautions, and instructions in this manual cannot cover all possible conditions or situations that could occur. Exercise common sense and caution when installing/using this product.

Assembly Instructions

- 1. Remove the cot and end bar supports from the carry bag.
- 2. Set aside both end bar supports.
- 3. Fold out the legs and let the cot stand on the ground. Be cautious when unfolding the legs to avoid pinching fingers and hands.
- 4. Slide the shorter end bar through the fabric pocket on one end of the cot, making sure the notches on the end bar are positioned as shown in Figure 3. The notch will fit over the button on the cot when positioned correctly. Push down the lock into place.
- 5. After securing the shorter bar, repeat Step 4 with the r remaining end bar on the opposite end of the cot. It may be necessary to stretch the fabric to get the longer end bar into position. (See EZ-Set Mechanism Box)

Fig 2

6. Secure the rod latches as shown in Figure 4 for each corner.







EZ-Set Mechanism



Insert mini-diameter tube into the hole and swivel it as the rotation arrow shows. Make sure the square tube press down exactly into the notch until it's locked.



This "EZ-Set Mechanism" makes assembling this cot easier than many traditional cots. This function based on other three corners are fixed.





SG05.20