



Congratulations on your Guide Gear® purchase.

Enjoy your new Guide Gear® item with confidence, knowing it has been designed and built to deliver dependable quality and performance at an exceptional value.

Item #167005 Guide Gear® Campfire Swing Grill



For assistance with your product, please contact the Sportsman's Guide customer service at 1-800-888-3006 Mon.-Fri. 7:00am to 9:00pm, Sat.-Sun. 8:00am to 8:00pm CST or go to sportsmansguide.com/customerservice/contactus



⚠ WARNING: ALWAYS read and understand all warnings, cautions, installation and use instructions prior to installing or using this product. Failure to follow all warnings, cautions and instructions may result in fire or explosion, which could cause property damage, serious injury, or death.

⚠ WARNING: For outdoor use only. **NEVER** use in any building, garage, other enclosures or under any structure. Not for commercial use.

⚠ WARNING: NEVER leave children or pets unattended near the product. Not intended for use by children.

NEVER attempt to modify this product or subject it to an installation or use for which it was not designed. Doing so may result in damage and/or serious injury.


⚠ CAUTION: all surfaces of this product are hot with in operation. To avoid burns, **NEVER** touch the product until it has completed cooled. ALWAYS use heat-resistant gloves or hot pads when touching product.

NEVER move or store this product until all items are completely cooled to touch.

NEVER place hot tools onto combustible surfaces such as but not limited to, grass, wood decks, or furniture.

The warnings, cautions, and instructions in this manual cannot cover all possible conditions or situations that could occur. Exercise common sense and caution when using this product. Always be aware of the environment and ensure that the product is used in a safe and responsible manner.

Save these instructions for future reference for anyone that is assembling or operating this product.



Assembly Step:

Step 1: Assemble the parts as the diagram illustrates.

Step 2: Pound the post into the ground for a firm foundation

Step 3: Now your Campfire Grill is ready

Once completely cooled - store and transport in the carry bag provided.

CARE INSTRUCTIONS:

NEVER use oven cleaner or abrasive cleaners as they will damage this product. **NEVER** clean any part of this product in a self-cleaning oven as it may damage the finish.

Wipe surfaces with a mild dish-washing detergent or baking soda. Rinse and clean with water.