



LUBEQ Corporation
1700 Todd Farm Drive
Elgin, IL 60123

Grease Lubricator with Pail	Technical Brief	03/25/2009
NSN 4930-00-244-4859	Assembly Instructions	



1. Pump
2. Dust Cover
3. Pressure Spring
4. Handle
5. Follower Plate
6. Discharge Hose Assembly
7. Pail



LUBEQ Corporation
1700 Todd Farm Drive
Elgin, IL 60123

Grease Lubricator with Pail	Technical Brief	03/25/2009
17695	Assembly Instructions	

Parts List:

- Grease Lubricator with Pail
- 6 ft. Connecting Hose
- Spout with Hydraulic Coupler



Assembly Instructions

1. Fill the drum with grease.
2. Insert the follower plate pump and the dust cover into the drum.
3. Attach dust cover tighten bolts to firmly attach dust cover to drum.
4. Attach the pump handle to pump (see photo).
5. Attach the hose to the pump.