


Congratulations on your CASTLECREEK® purchase.

We're proud to help you furnish and enhance the place you call home. Whether indoors or outside, CASTLECREEK® is the perfect choice for comfortable living at an exceptional value.

Item #676471 CASTLECREEK® Lattice Air Conditioner Screen




For assistance with your product, please contact the Sportsman's Guide customer service at 1-800-888-3006 Mon.-Fri. 7:00am to 9:00pm, Sat.-Sun. 8:00am to 8:00pm CST or go to sportsmansguide.com/customerservice/contactus



sportsmansguide.com 676471 - CC AC Screen 1 of 2

Lattice Air Conditioner Screen Assembly Instructions



ADDITIONAL DETAILS / WARNINGS:

- ▲ WARNING: CHOKING HAZARD- Contains small parts- keep parts and packaging away from children and pets.
- ♠ WARNING: Do not stand or hang on AC screen. Read and understand all warnings, cautions, assembly, installation and use instructions prior to assembling, installing or using this product. Failure to follow all warnings, cautions and instructions may result in serious injury or damage to

Confirm all parts are present before assembly. If any part is missing, cracked or damaged, please contact Sportsman's Guide customer service before assembly.

Assemble product on a soft surface (like the cardboard box) to protect from scratching or damaging the item and other surfaces


Tools required (not included): Philips screwdriver.

At least two people are recommended for safe assembly and installation of this product.

Once assembled, make sure the product is placed on a firm, level surface and secured.

STEP 1


Use four Screws (A) to attach hinges (preassembled to the Center Screen (1)) to the Right Side Screen (2).



STEP 2

personal property.

Use four Screws (A) to attach hinges on the Center Screen (1) to the Left Side Screen (3).



ASSEMBLY COMPLETE.

