




Electric Grinder Foot Pedal

Owner's Manual



⚠ WARNING: Read carefully and understand all ASSEMBLY AND OPERATION INSTRUCTIONS before operating. Failure to follow the safety rules and other basic safety precautions may result in serious personal injury.

Item # 1A-EG008

READ & SAVE THESE INSTRUCTIONS

Congratulations on your Guide Gear™ purchase.

Take your game to the next level with field-tested Guide Gear™ products for a confident, competitive edge that strikes the perfect balance between performance and value.

For future reference, please complete the owner's record below:

Serial Number/Lot Date Code: _____

Purchase Date: _____

Save the receipt, warranty, and this manual. It is important that you read the entire manual to become familiar with this product before you begin using it.

This electric grinder foot pedal is designed for certain applications only. The Sportsman's Guide and Northern Tool and Equipment are not responsible for issues arising from modification or improper use of this product such as an application for which it was not designed. We strongly recommend that this product not be modified and/or used for any application other than that for which it was designed.

DO NOT RETURN TO THE STORE.

For help with assembly, service, or missing/defective parts,

Please call our toll-free number:

1-800-545-9633

Or email:

customerservice@forcome.com

M-F 8:00 AM - 6:00 PM CST

Saturday 8:00 AM - 4:00 PM CST

Table of Contents

Intended Use 4

Technical Specifications 4

Important Safety Information 4

Grounding 6

Extension Cords 7

Operating Instructions 8

Replacement Parts 9

Limited Warranty 10

Intended Use

Put your pedal to the metal to propel your meat grinder to efficient new heights. A simple touch of this Guide Gear® Grinder Foot Pedal is all you need to stop and start your Guide Gear® Grinder hands-free. That frees you up for keeping the grinder filled to the brim to maximize your efficiency. Compatible with all Guide Gear® series electric grinders (sold separately).

Technical Specifications

Property	Specification
Cord Length	8 feet
Amperage	15 Amps
Weight	1.72 pounds
Material	Plastic
Compatible Grinders	Guide Gear Electric Grinders #22, #32, & #42
Attachment Method	Simply plug your foot pedal into grinder

Important Safety Information

WARNING

- Read and understand all instructions. Failure to follow all instructions may result in serious injury or property damage.
- The warnings, cautions, and instructions in this manual cannot cover all possible conditions or situations that could occur. Exercise common sense and caution when using this electric grinder foot pedal. Always be aware of the environment and ensure that the electric grinder foot pedal is used in a safe and responsible manner.
- Do not allow persons to operate or assemble the electric grinder foot pedal until they have read this manual and have developed a thorough understanding of how it works.
- Do not modify this electric grinder foot pedal in any way. Unauthorized modification may impair the function and/or safety and could affect the life of the product. There are specific applications for which the product was designed.
- Use the right grinder for the job. DO NOT attempt to force small equipment to do the work of larger industrial equipment. There are certain applications for which this electric grinder foot pedal was designed. This electric grinder foot pedal will be safer and do a better job at the capacity for which it was intended. DO NOT use this electric grinder foot pedal for a purpose for which it was not intended.
- Industrial or commercial applications must follow OSHA requirements.

WARNING

- This product may contain chemicals known to the state of California to cause cancer, birth defects, or other reproductive harm.
- Handling power cords on corded products may expose you to lead, a chemical known to the state of California to cause cancer and birth defects or other reproductive harm. Wash your hands after handling.

WARNING

WORK AREA SAFETY

- Inspect the work area before each use. Keep work area clean, dry, free of clutter, and well-lit. Cluttered, wet, or dark work areas can result in injury. Using the product in confined work areas may put you dangerously close to cutting tools and rotating parts.
- Do not allow the product to come into contact with an electrical source. The electric grinder foot pedal is not insulated and contact will cause electrical shock.
- Keep children and bystanders away from the work area while operating the electric grinder foot pedal. Do not allow children to handle the product.
- Be aware of all power lines, electrical circuits, water pipes, and other mechanical hazards in your work area. Some of these hazards may be hidden from your view and may cause personal injury and/or property damage if contacted.

WARNING

PERSONAL SAFETY

- Stay alert, watch what you are doing, and use common sense when operating the electric grinder foot pedal. Do not use the electric grinder foot pedal while you are tired or under the influence of drugs, alcohol, or medication. A moment of inattention while operating the electric grinder foot pedal may result in serious personal injury.
- Dress properly. Do not wear loose clothing, dangling objects, or jewelry. Keep your hair, clothing and gloves away from moving parts. Loose clothes, jewelry, or long hair can be caught in moving parts.
- Wear the proper personal protective equipment when necessary. Use ANSI Z87.1 compliant safety goggles (not safety glasses) with side shields, or when needed, a face shield. This applies to all persons in the work area.
- Do not overreach. Keep proper footing and balance at all times.
- Do not use the electric grinder foot pedal when tired or under the influence of drugs, alcohol or medication.

CAUTION

PRODUCT USE AND CARE

- Electric grinder foot pedals are safer and do a better job when used in the manner for which they are designed. Plan your work, and use the correct product for the job.
- Check for damaged parts before each use. Carefully check that the product will operate properly and perform its intended function. Replace damaged or worn parts immediately. Never operate the product with a damaged part.
- Do not use a product with a malfunctioning switch.

- Disconnect the power supply from the product and place the switch in the locked or off position before removing blade, making any adjustments, changing accessories, cleaning or storing the grinder. Such preventive safety measures reduce the risk of starting the electric grinder foot pedal accidentally.
- Store the product when it is not in use. Store it unplugged in a dry, secure place out of the reach of children. Inspect the electric grinder foot pedal for good working condition prior to storage and before re-use.
- Use only accessories that are recommended by the manufacturer for use with your product. Accessories that may be suitable for one grinder may create a risk of injury when used with another grinder.
- Do not use electric foot pedal and grinder outdoors. This foot pedal is intended for household use only.
- Do not use in wet areas. Do not put in water or other liquids. Do not operate with wet hands or while standing on a wet floor. Do not use if it is wet.

Grounding

WARNING

- This electric foot pedal must be grounded while in use to protect the operator from electrical shock. This unit is equipped with an electrical cord that has an equipment grounding conductor and a grounding plug. The plug **MUST** be plugged into a matching receptacle that is properly installed and grounded in accordance with ALL local codes and ordinances.
- **DO NOT MODIFY THE PROVIDED PLUG.** If it will not fit the receptacle, have the proper receptacle installed by a qualified electrician.
- **CHECK** with a qualified electrician or service person if you do not completely understand the grounding instructions, or if you are not sure the grinder and foot pedal is properly grounded.

Grounded Slicers: Slicers with 3-Prong Plugs

Grinders and foot pedals marked with **Grounding Required** have a 3-wire cord and 3-prong grounding plug. The plug must be connected to a properly grounded outlet. If the grinder and foot pedal should electrically malfunction or break down, grounding provides a low resistance path to carry electricity away from the user, reducing the risk of electric shock. (See Figure A.)

The grounding prong in the plug is connected through the green wire inside the cord to the grounding system in the grinder and foot pedal. The green wire in the cord must be the only wire connected to the grinder's and foot pedal's grounding system and must never be attached to an electrically live terminal.

Your grinder and foot pedal must be plugged into an appropriate outlet, properly installed and grounded in accordance with all codes and ordinances. The plug and outlet should look like those in the following illustration.




FIGURE A

Double Insulated Grinders and Foot Pedals: Grinders and Foot Pedals with Two-Prong Plugs

Grinders and Foot Pedals marked **Double Insulated** do not require grounding. They have a special double insulation system which satisfies OSHA requirements and complies with the applicable standards of Underwriters Laboratories, Inc., the Canadian Standard Association, and the National Electrical Code. (See Figure B.)

Double insulated grinders and foot pedals may be used in either of the 120 volt outlets shown in the following illustration.




FIGURE B

Extension Cords

WARNING

- IT IS RECOMMENDED THAT YOU DO NOT USE AN EXTENSION CORD WITH THIS PRODUCT.
- IF YOU DO, USE A PROPER EXTENSION CORD. Make sure your extension cord is in good condition. When using an extension cord, be sure to use one heavy enough to carry the current your product will draw. An undersized cord will cause a drop in line voltage, resulting in loss of power and cause overheating.
- Be sure your extension cord is properly wired and in good condition. Always replace a damaged extension cord or have it repaired by a qualified person before using it. Protect your extension cords from sharp objects, excessive heat and damp or wet areas.
- Grounded grinders and foot pedals require a 3-wire extension cord. Double Insulated grinders and foot pedals can use either a 2- or 3-wire extension cord, again it is recommended that an extension cord not be used with this product.
- As the distance from the supply outlet increases, you must use a heavier gauge extension cord. Using extension cords with inadequately sized wire causes a serious drop in voltage, resulting in loss of power and possible grinder and foot pedal damage.


- The smaller the gauge number of the wire, the greater the capacity of the cord. For example, a 14-gauge cord can carry a higher current than a 16-gauge cord. Minimum extension cord wire size is shown in the following table:

Minimum Wire Size Of Extension Cords				
Nameplate AMPS	Cord Length			
	25'	50'	100'	150'
0-6	18 AWG	16 AWG	16 AWG	14 AWG
6-10	18 AWG	16 AWG	14 AWG	12 AWG
10-12	16 AWG	16 AWG	14 AWG	12 AWG
12-16	14 AWG	12 AWG	NOT RECOMMENDED	

- When using more than one extension cord to make up the total length, make sure each cord contains at least the minimum wire size required.
- If you are using one extension cord for more than one grinder and foot pedal, add the nameplate amperes and use the sum to determine the required minimum cord size.
- Make sure your extension cord is properly wired and in good electrical condition. Always replace a damaged extension cord or have it repaired by a qualified electrician before using it.
- Protect your extension cords from sharp objects, excessive heat, and damp or wet areas.

Operating Instructions

1. Plug your grinder into this 15 amp grinder foot pedal plug.



2. Plug the pedal into a 110V outlet.



3. Now you can start and stop your grinder with a tap of your foot. The grinder foot switch keeps both hands free when stuffing casings or filling ground meat bags.



Replacement Parts

- For replacement parts and technical questions, please call Customer Service at **1-800-545-9633** or email at customerservice@forcome.com.
- Not all product components are available for replacement. The pictures provided are a convenient reference to the location and position of parts in the assembly sequence.
- When ordering parts, the following information will be required: item description, item model number, item serial number/item lot date code, and the replacement part reference number.
- The distributor reserves the rights to make design changes and improvements to product lines and manuals without notice.

Limited Warranty

The Sportsman's Guide and Northern Tool and Equipment Company, Inc. ("We" or "Us") warrants to the original purchaser only ("You" or "Your") that the Guide Gear product purchased will be free from material defects in both materials and workmanship, normal wear and tear excepted, for a period of **one year** from date of purchase. The foregoing warranty is valid only if the installation and use of the product is strictly in accordance with product instructions. There are no other warranties, express or implied, including the warranty of merchantability or fitness for a particular purpose. If the product does not comply with this limited warranty, Your sole and exclusive remedy is that We will, at our sole option and within a commercially reasonable time, either replace the product or product component without charge to You or refund the purchase price (less shipping). This limited warranty is not transferable.

Limitations on the Warranty

This limited warranty does not cover: (a) normal wear and tear; (b) damage through abuse, neglect, misuse, or as a result of any accident or in any other manner; (c) damage from misapplication, overloading, or improper installation; (d) improper maintenance and repair; and (e) product alteration in any manner by anyone other than Us, with the sole exception of alterations made pursuant to product instructions and in a workmanlike manner.

Obligations of Purchaser

You must retain Your product purchase receipt to verify date of purchase and that You are the original purchaser. To make a warranty claim, contact Us at 1-800-545-9633, identify the product by make and model number, and follow the claim instructions that will be provided. The product and the purchase receipt must be provided to Us in order to process Your warranty claim. Any returned product that is replaced or refunded by Us becomes our property. You will be responsible for return shipping costs or costs related to Your return visit to a retail store.

Remedy Limits

Product replacement or a refund of the purchase price is Your sole remedy under this limited warranty or any other warranty related to the product. We shall not be liable for: service or labor charges or damage to Your property incurred in removing or replacing the product; any damages, including, without limitation, damages to tangible personal property or personal injury, related to Your improper use, installation, or maintenance of the product or product component; or any indirect, incidental or consequential damages of any kind for any reason.

Assumption of Risk

You acknowledge and agree that any use of the product for any purpose other than the specified use(s) stated in the product instructions is at Your own risk.

Governing Law

This limited warranty gives You specific legal rights, and You also may have other rights which vary from state to state. Some states do not allow limitations or exclusions on implied warranties or incidental or consequential damages, so the above limitations may not apply to You. This limited warranty is governed by the laws of the State of Minnesota, without regard to rules pertaining to conflicts of law. The state courts located in Dakota County, Minnesota shall have exclusive jurisdiction for any disputes relating to this warranty.



Distributed by:

The Sportsman's Guide

And

Northern Tool & Equipment Company, Inc.

Burnsville, Minnesota 55306

www.sportsmansguide.com www.northerntool.com