



## Quiver Magnet H2O #61135-7 v2

Thank you for purchasing the Quiver Magnet H2O. To see more Lucky Duck™ products please visit your local Sporting Goods dealer or online at [www.luckyduck.com](http://www.luckyduck.com).

**Step 1:** Carefully remove Quiver Magnet H2O from its packaging.

**Step 2:** Unscrew the cover from the Quiver Magnet H2O battery module by turning counter-clockwise.

**Step 3:** Insert 2 "AA" batteries and secure in place by pivoting the locking battery tabs over the batteries.

**DO NOT MIX OLD & NEW BATTERIES. DO NOT MIX ALKALINE, STANDARD (CARBON ZINC) OR RECHARGEABLE (ni-cad, ni-mh, etc) BATTERIES.**

**Step 4:** Replace the cover and ensure the cover is secured tightly for a waterproof seal.

**Step 5:** Attach the anchor and cord to the loop at the front of the module.

**Step 6:** The Quiver Magnet H2O has a water activation switch that turns the product on when set in the water and turns the product off when removed from the water. When the two silver contacts on the bottom of the module are both submerged under water the product turns on. If the Quiver Magnet H2O continues to remain on when removed from the water simply wipe the two silver contacts with your hand or clothing. The product will turn off.

**Step 7:** Place the Quiver Magnet H2O directly in the water among your decoy spread and watch your decoys come alive.

**Tip:** To test the product out of the water simply assemble your Quiver Magnet H2O as described above and set the silver contacts on a wet towel or in a small water bowl.

### Storage:

After each hunt check the battery module to see if moisture is present inside the module. If moisture is present, leave the cover off the module until it is dry. Remove the batteries from the module while in storage. **The products electrical components have a slow drain if the battery is connected even when the product is not running.**

**Lucky Duck™ warrants this product against all manufacturing defects for a period of 1 year from date of purchase. Proof of purchase is required. Abuse of the product (submerged in water, dropped, mistreatment etc.) is not covered. Please return and exchange the defective unit to the store where you purchased the product. If the store will not accept the return, please call customer service at 715-338-3183.**

### Lucky Duck™

A Division of Expedite International Inc.

1950 8<sup>th</sup> Ave

Baldwin, WI 54002

Customer Service 715-338-3183

[www.luckyduck.com](http://www.luckyduck.com)

