



**-PLEASE FOLLOW ALL OF THE DIRECTIONS IN THIS MANUAL CAREFULLY.
CAUTION: ALWAYS PRACTICE SAFE FIREARMS HANDLING!**

**-BE SURE THAT THE FIREARM IS UNLOADED AND SAFE BEFORE PERFORMING ANY OF THE
FOLLOWING PROCEDURES!**

-BE SURE THAT THE FIREARM IS POINTED IN A SAFE DIRECTION AT ALL TIMES!

-CAUTION: AVOID SHINING THE LASER IN YOUR EYES OR INTO ANYONE ELSE'S EYES!

FEATURES:

Sleek compact low profile design.
Designed to be securely mounted onto most Weaver/ Picatinny style rails.
Easy to reach Side to Side On/Off switch
Laser is fully adjustable for Windage and Elevation.

SPECIFICATIONS:

Maximum output power: <5mW	Length: 2.25"
Wavelength: 635-655 nm	Width: 1.11"

Battery type: AG13 or LR44 (1.5V button cell battery) Height: 0.90"

Weight: 1 oz.

Requires two Batteries

INSTALLATION:

To mount the laser onto a Weaver/ Picatinny style rails, first unscrew and remove the Allen Head Bolt from the mount of the laser using the supplied Allen wrench. Set aside the Rail Clamp and Allen Head Bolt.

Place and position the laser onto the firearm rail so that a recoil slot aligns up with one of the laser Mount Bolt Holes. Insert the Allen Head Bolt through the laser body & firearm rail recoil slot and attach the Rail Clamp to the opposite side of the laser body. Use the Allen wrench to tighten the Allen Head Bolt into the Rail Clamp. Make sure that the Rail Clamp slot is interfacing with the Rail Clamp Tab on the side of the laser body.

Tighten the Allen Head Bolt until it is snug. Be careful to not over-tighten the Mount Bolt or it may cause damage to the laser. Your laser is now securely mounted and ready for use.

REMOVAL:

Using the supplied Allen Wrench and carefully loosen (counter-clockwise) the Allen Head Bolt in the mount, when you have removed the Allen Head Bolts the laser can be removed from the rail.

ON/OFF SWITCH FUNCTION:

The laser is equipped with a Side to Side ON/OFF Switch. First, make sure the laser is pointed in a safe direction. To turn the laser ON, push the right side of the ON/OFF Switch to the Left. To turn the laser OFF, push the left side of the ON/OFF Switch to the Right.

WINDAGE AND ELEVATION ADJUSTMENT:

To adjust the Windage of the laser, insert the provided Allen wrench into the Windage Set Screw located on the Left side of the laser body. Turn the Windage Set Screw Clockwise to adjust Left and Counter-clockwise to adjust Right.

To adjust the Elevation of the laser, insert the provided Allen wrench into the Elevation Set Screw located on the bottom of the laser body. Turn the Elevation Set Screw Clockwise to adjust laser Down and Counter-clockwise to adjust the Laser Up.

TIP: The quickest method to zero your laser is to first adjust the laser to your iron sights. Then make the necessary fine adjustments at the shooting range

BATTERY REPLACEMENT:

To replace the batteries in your laser, first turn the laser to the OFF position. The Battery Cap is the round cap with a slot machined into it, located on the bottom of the laser body. Use a flat blade screw driver or small coin to turn the Battery Cap Counter Clockwise for removal.

Once the Battery Cap is removed, remove the old batteries and discard it in the proper manner. The 2nd battery will sometimes stick to the inside of the Battery Cap. Only use new AG13 or LR44 batteries with the laser. DO NOT use a different type of battery, as this may cause damage to the unit. DO NOT mix old batteries with new batteries.

Place the new batteries into the laser, making sure that both of the battery's Positive Sides (+) are facing out and that the batteries are centered in the cavity. Once the batteries are in place, place the Battery Cap over the top battery and screw the cap Clockwise until the cap is flush with the bottom of the laser body. If there is some resistance or the cap does not close flush, make sure the bottom battery is centered in the cavity, so that the cap can screw down and around both batteries. Next, test the function of the laser. If the laser does not turn ON, check to make sure that both of the batteries are installed correctly.